

FORD Bronco

SKU: BBFTA006



Thank you for purchasing the Blackboost Ford Bronco FTA Adapter.

This guide will provide you the instructions on how to install the BlackBoost FTA Adapter.

Content of the Box

- | | | |
|----------------|---|---|
| 1. FTA Adapter | - | 1 |
| 2. Screws | - | 3 |



Compatibility

Ford Bronco (U725) – 2.3L EcoBoost I4 Turbo – (2021+)

Ford Bronco (U725) – 2.7L EcoBoost V6 TT – (2021+)

Ford Bronco (U725) – 3.0L EcoBoost V6 TT – (2023+)

Step 1

Unscrew all 3 screws off the diverter valve.



Step 2

Disconnect the cable and remove the diverter valve completely to install the BlackBoost FTA.



Step 3

Place the BlackBoost FTA on top of the diverter valve.
Rotate it accordingly for the screws to be placed in correctly.



Step 4

Place the screws and install the BlackBoost FTA and the diverter valve



Step 5

Reconnect the wire back to the diverter valve.





Thank you again for your purchase.

Hope you enjoy, drive safe & responsibly.

Disclaimer: *In no event will BlackBoost, or its affiliates be liable for any damage to your car, its components or yourself. Please be aware of local laws and regulations prior to installation.*